



GPIB Analyzer Help

March 2003 Edition, Part Number 370686A-01

This help file describes the GPIB analyzer software. The GPIB analyzer is an application that you can use for testing, debugging, and analysis. It can monitor, capture, and participate in bus activity on the GPIB.

To navigate this help file, use the **Contents**, **Index**, and **Search** tabs to the left of this window.

For more information about this help file, refer to the following topics:

[Conventions](#)—formatting and typographical conventions in this help file

[Glossary](#)

[Important Information](#)

[Technical Support and Professional Services](#)

To comment on the documentation, email techpubs@ni.com

© 1995–2003 National Instruments Corporation. All rights reserved.

Conventions

This help file uses the following conventions:

- » The » symbol leads you through nested menu items and dialog box options to a final action. The sequence **File»Page Setup»Options** directs you to pull down the **File** menu, select the **Page Setup** item, and select **Options** from the last dialog box.
- bold** Bold text denotes items that you must select or click in the software, such as menu items and dialog box options. Bold text also denotes parameter names, emphasis, or an introduction to a key concept.
- green Underlined text in this color denotes a link to a help topic, help file, or Web address.
- italic* Italic text denotes variables or cross references. This font also denotes text that is a placeholder for a word or value that you must supply.
- monospace Text in this font denotes text or characters that you should enter from the keyboard, sections of code, programming examples, and syntax examples. This font is also used for the proper names of disk drives, paths, directories, programs, subprograms, subroutines, device names, functions, operations, variables, filenames and extensions, and code excerpts.

Glossary

Symbol	Prefix	Value
n	nano	10^{-9}
μ	micro	10^{-6}
m	milli	10^{-3}

ASCII	American Standard Code for Information Interchange
DIO	digital input/output
EOI	end or identify
EOS	End-of-String
FIFO	first-in-first-out
GPIB	General Purpose Interface Bus
hex	hexadecimal
HS488	high-speed IEEE 488 transfers
IEEE	Institute of Electrical and Electronic Engineers
LED	light-emitting diode
m	meters
s	seconds

GPIB Analyzer Overview

The GPIB analyzer is an application that you can use for testing, debugging, and analysis. It can monitor, capture, and participate in bus activity on the GPIB. You can use the GPIB analyzer to test and debug your own applications by monitoring and capturing GPIB activity while your application is running. The analyzer also has tools to help you analyze the data that you capture. Analyzing this data can help you solve many of the difficulties associated with GPIB communication, such as addressing inconsistencies, protocol violations, and simple bus timeout conditions.

The *GPIB Analyzer User Manual* includes a tutorial chapter and a chapter containing examples to show you how you might use the analyzer. The user manual is available on your *NI-488.2 for Windows* CD. To view this document online, insert your *NI-488.2 for Windows* CD. When the **NI-488.2 for Windows** screen appears, select the **Getting Started Documentation** option. The Getting Started Documentation utility helps you find the documentation you want to view.

For detailed information about using the GPIB analyzer, see [GPIB Analyzer Features](#).

See also:

[Capturing Data with the GPIB Analyzer](#)

[Analyzing Captured Data with the GPIB Analyzer](#)

[Exiting the GPIB Analyzer](#)

Capturing Data with the GPIB Analyzer

The analyzer can capture and display data, including any combination of the following GPIB events: data transfers, command transfers, control line transitions, handshake line transitions, and parallel poll responses. You can participate in handshaking or do a nonintrusive capture.

You might want to capture and display data based on a specific bus event without knowing when the event might occur. In this case, you can specify a trigger condition and capture any number of events before and after the trigger condition occurs. The capture operation proceeds according to the settings configuration.

The analyzer can perform the acceptor handshake while capturing, and it can timestamp captured events. The number of recorded capture events can be configured to be between 10 and 99999999 and is limited by the memory available on your computer.

Note the following capabilities concerning captures:

- You can switch back and forth between [Capture](#) and [Capture & Trigger](#) during the capture without losing data.
- The GPIB analyzer timer resolution is 50 ns, so the fastest rate of capturing GPIB events possible is one GPIB event every 50 ns.
- Multiple capture displays can be viewed simultaneously.

Analyzing Captured Data with the GPIB Analyzer

The GPIB analyzer provides several features to help you analyze data that you have captured:

- Use markers for highlighting and examining specific transactions in the captured data, and for determining elapsed time between captured events.
- Use the flexible pattern-search utility to locate specific bus patterns.
- Store captured data to disk for later review in the capture display.
- Print captured data to a selected printer.

You can reload previously saved capture events for later review and analysis. You can even have multiple capture displays open, so that you can analyze current bus activity in one display and the previously captured data in another display.

Exiting the GPIB Analyzer

Choose **File»Exit** to close the GPIB analyzer application. The analyzer prompts you to save any capture display that contains unsaved GPIB events. The current settings for capturing and triggering are saved automatically, and they are automatically loaded the next time you start the GPIB analyzer application.

GPIB Analyzer Features

The GPIB analyzer, created with the National Instruments LabWindows/CVI development environment, has several major features.

[Settings configuration](#)—Allows configuration of capture and trigger settings.

[Action window](#)—Starts and stops capturing and/or triggering.


[Bus Monitor window](#)—Displays and allows you to modify the state of each of the GPIB data and control lines.

[Capture Display window](#)—Displays captured GPIB events.

[Search capability](#)—Allows searches within a capture display.

The main GPIB analyzer window is shown below. The Action and Bus Monitor windows are always open.


Click areas of the picture to see detailed information about each menu, button, and option available in the main window.



Settings Configuration

Capture and trigger settings can be configured by selecting **Change Settings...** from the **Settings** menu. The following picture shows the **Settings** configuration dialog box.

Click areas of the picture to see detailed information about each menu, button, and option available in the **Settings** dialog box.



The configured settings apply only to active capture displays. Note that the settings in this window cannot be changed unless capturing and triggering are turned off (use the [Action](#) window to turn off capturing and triggering).

See also:

[Configure Capture Settings](#)

[Configure Trigger Settings](#)

Action Window

The Action window contains controls you can use to turn capturing and/or triggering on and off. When the GPIB analyzer application is started, capture and trigger are both off.

The Action window, shown below, is always open. If the window is hidden, use **Windows»Action Window** to bring it to the front.

Click areas of the picture to see detailed information about the Action window.




Note that you can switch back and forth between [Capture](#) and [Capture & Trigger](#) during the capture without losing data.

Bus Monitor Window

The Bus Monitor window allows you to monitor and control each of the 16 GPIB data and control lines. It also allows you to accept GPIB data, one byte at a time. The Bus Monitor window, shown below, is always open. If the Bus Monitor window is hidden, use **Windows»Bus Monitor** to bring it to the front.

Click areas of the picture below to see detailed information about each button and option available in the Bus Monitor window.




Capture Display Window

The Capture Display window displays captured GPIB events. You can have more than one capture display open at one time, and capture displays can be either active or inactive. Active capture displays show GPIB events as they are being captured. Inactive capture displays show previously captured events, so that they are unaffected by newly captured GPIB events.

To open an active Capture Display window, choose **New Capture Display** from the **File** menu in the main window. To open an inactive **Capture Display** window, choose **Open Capture File...** from the **File** menu in the main window. To switch between active and inactive capture modes, you can click the **Switch to Active (Inactive) Display** button to toggle between the two modes. The following picture shows an example of an inactive Capture Display window.

Click areas of the picture to see detailed information about each menu, button, and option available in the Capture Display window.




Search Capability

The **Find...** and **Find Next** buttons in the capture display allow you to search for specific GPIB data and control line patterns, data strings, or trigger points in an inactive capture display.

To do a new search, click the **Find...** button in an inactive capture display to bring up a **Find** dialog box similar to the one shown in the following picture. To repeat the search, click the **Find Next** button in the inactive capture display.

Click areas of the picture below to see detailed information about each button and option available in the **Find** dialog box.



To find a trigger point in the Capture Display window, check the **Find Trigger** checkbox and then click the **Find** button.

To find a particular data and control line pattern, set the pattern of the data lines using either the **ASCII** or **Hex** edit controls or the **D8** to **D1** spin controls (for binary values), and set the pattern of the control lines using the **EOI**, **ATN**, **SRQ**, **REN**, **IFC**, **NRFD**, **NDAC**, and **DAV** spin controls. Notice that the spin controls allow you to select **0** (unasserted), **1** (asserted), or **x** (don't care) for each data and control line. When the data and control lines have been selected, click the **Find** button.

To find a series of GPIB data and control line patterns, use the **Insert Above**, **Insert Below**, and **Delete** buttons to add and remove entries from the **Find String** list box until it contains the desired series of GPIB data and control line patterns. Click the **Find** button to conduct the search.

Exiting the GPIB Analyzer

Choose **File»Exit** to close the GPIB analyzer application. The analyzer prompts you to save any capture display that contains unsaved GPIB events. The current settings for capturing and triggering are saved automatically, and they are automatically loaded the next time you start the GPIB analyzer application.

View/Change the State of GPIB Data and Control Lines

You can view or change the state of the GPIB data and control lines from within the Bus Monitor window.

The state of the GPIB data and control lines is displayed on the row of LEDs and the upper **ASCII** and **Hex** edit controls. You can alter the value of the GPIB data and control lines using the row of binary switches and the lower **ASCII** and **Hex** edit controls.

You can enter the GPIB data value as an ASCII value in the **ASCII** edit control, a hexadecimal value in the **Hex** edit control, or a binary value in the **8** to **1** binary switches. Note that the GPIB data value is replicated in all three representations: ASCII, hexadecimal, and binary.

You can enter the GPIB control value using the **EOI**, **ATN**, **SRQ**, **REN**, **IFC**, **NRFD**, **NDAC**, and **DAV** binary switches. The up position corresponds to the assertion of the line.

To accept a byte of data on the bus, use the **NRFD** and **NDAC** binary switches to simulate the IEEE 488 handshake, or use the **Accept Byte** button, which automatically toggles **NRFD** and **NDAC** in the correct sequence. The **Accept Byte** button is enabled by clicking the **Enable Accept Byte** button.

If you are using the Bus Monitor to assert GPIB lines, do not use the NI-488.2 `ibfind` or `ibdev` functions. These functions will unassert the lines on the bus, even though the switches in the Bus Monitor window show that the lines are asserted. If you encounter this problem, click the **Unassert Lines** button and avoid using the `ibfind` or `ibdev` functions.

Accept a Single Byte

To accept a single byte of data on the GPIB, first click the **Enable Accept Byte** button in the Bus Monitor window. Then click the **Accept Byte** button in the Bus Monitor window. This action automatically toggles the NRFD and NDAC lines in the correct IEEE 488 handshaking sequence to accept a single byte. If you disable the Accept Byte feature, you can control the NRFD and NDAC lines manually using the binary switches in the Bus Monitor window.

If you try to accept a byte when no GPIB device is currently trying to source a byte (DAV unasserted), toggling the handshake lines or clicking **Accept Byte** has no effect.

Start and Stop Capture of Data

To begin capturing data, complete the following steps:

1. Configure the capture settings and trigger conditions using **Settings»Change Settings...**
2. If an active display is not already open, open a new Capture Display window using **File»New Capture Display**.
3. Bring the Action window to the front using **Windows»Action Window**.
4. Click the **Capture** or **Capture & Trigger** button in the Action window to begin capturing data.

To stop capturing new data, click the **Off** button in the Action window.

View Previously Captured Data

To open a Capture Display window to view previously saved GPIB events, choose **File»Open Capture File...**

Configure Capture Settings

Complete the following steps to configure the capture settings:

1. Click the **Off** button in the Action window. (Selecting **Windows»Action Window** brings the Action window to the front.)
2. Open the **Settings** dialog box by choosing **Settings»Change Settings...**
3. Configure the capture settings. Refer to the [Settings Configuration](#) section for details on all the capture settings you can configure.
4. When you are finished making changes, click **OK** in the **Settings** dialog box.

You can save your capture settings by choosing **Settings»Save Settings As...** and reload them by choosing **Settings»Load Settings...**

Configure Trigger Settings

Complete the following steps to configure the trigger settings for your capture:

1. Click the **Off** button in the Action window. (Selecting **Windows»Action Window** brings the Action window to the front.)
2. Open the **Settings** dialog box by choosing **Settings»Change Settings...**
3. Configure the trigger settings. Refer to the picture in the [Settings Configuration](#) section for details on all the trigger conditions you can configure.
4. When you are finished making changes, click **OK** in the **Settings** dialog box.

You can save your trigger settings by choosing **Settings»Save Settings As...** and reload them by choosing **Settings»Load Settings...**

To use the configured trigger settings, start capture using the **Capture & Trigger** button in the Action window, instead of the **Capture** button.

Timestamp Capture Events

Timestamping shows you the elapsed time between GPIB events captured by the GPIB analyzer. The timestamp information appears in the timestamp column of the capture display.


To enable timestamping, check the **Enable Timestamping** checkbox in the **Settings** dialog box.

Do a Nonintrusive Capture

To prevent the GPIB analyzer from participating in acceptor handshaking, uncheck the **Participate in Acceptor Handshake** checkbox in the **Settings** dialog box. If this checkbox is checked, the analyzer participates in all handshaking on the GPIB. You might want to select this checkbox to slow down the GPIB transfers or to avoid overflow errors.

Avoid Overflow Errors

An overflow error occurs when the GPIB analyzer FIFO hardware buffer fills up with GPIB events faster than the software can receive them. If this happens, an error message with asterisks and the word "OVERFLOW" appears in the capture display, as shown in the following figure.



If an overflow error occurs, one or more GPIB events have been lost. You can usually avoid overflow errors by making one of the following changes:

- Check the **Participate in Acceptor Handshake** checkbox in the **Settings** dialog box and set the **Handshaking rate** to **Maximum**. This configuration causes the analyzer to hold off when the FIFO is almost full. It prevents high-speed GPIB data transfers when the FIFO is almost full, which can be a common cause of overflow errors.
- Uncheck the **Handshake Line Transitions** checkbox in the **Settings** dialog box. If this option is selected, you might capture up to six times as many GPIB events as when choosing to capture only data and command transfers. The reason for this is that when you enable the capture of handshake line transitions, you start getting GPIB events such as NDAC↑

and NRFD↓, which reflect the multiple changes that occur to the states of the GPIB handshake lines for each byte transferred on the GPIB. This high volume of events is likely to cause overflow errors.

- Uncheck the **Enable Timestamping** checkbox in the **Settings** dialog box. If you do not need to see the timestamping information, disabling this option can reduce the amount of data transferred from the FIFO and reduce the possibility for overflow errors.
- Uncheck the **Control Line Transitions** checkbox in the **Settings** dialog box. Some GPIB devices may toggle the control lines incorrectly, and overflow errors could result.
- Close all active capture displays while capturing. The analyzer captures GPIB events more efficiently if they do not need to be displayed immediately.
- Increase the **Retain up to _____ capture events** value in the **Settings** dialog box. This field specifies the maximum number of capture events retained in the capture buffer.

Save and Reload Capture/Trigger Settings

The analyzer uses the current capture and trigger settings until you change them again and automatically saves them when you exit the analyzer program. If you want to save the current settings for later use, use **Settings»Save Settings As...** Whenever possible, use the .SET extension for analyzer settings filenames.

To load a file of previously saved settings, use **Settings»Load Settings...**

View the Captured Data

You can view the captured GPIB events in either detailed display mode or summarized display mode. With detailed display mode, captured GPIB events are shown one per line. In summarized display mode, multiple events are combined on single lines. Line transitions are displayed on separate lines, but data and command transfers are grouped on the same line. In either display mode, lines are color coded based on the type of event captured. The following table shows the color coding scheme.

Color Coding in the Capture Display

Type of Event	Color
Data transfers	Blue
Command transfers	Green
Control line transitions	Black
Handshake line transitions	Black
Parallel poll responses	Black
Trigger event	Dotted box
Overflow	White

[Read the Timestamp Column](#)

[Read the Mnemonics Column](#)

Read the Timestamp Column

In detailed mode, where each line represents a single capture event, the timestamp value represents the time elapsed between the event on that line and the event on the previous line. So, if you want to determine the time elapsed between the capture of the first event and the fifth event, add up the timestamp values on the second, third, fourth, and fifth lines. Alternately, you can switch to an inactive display using the **Switch to Inactive Display** button and put markers on the first and last event of interest, then use the **From** and **To** fields in the **Markers & Statistics** group box to have the GPIB analyzer calculate a **Time elapsed** value for you.

In summarized mode, where more than one event can be present on a line, the timestamp value represents the time elapsed between the first event on that line and the first event on the previous line.

The timestamp column in the capture display shows the timestamp in a minute, second, millisecond, microsecond, and nanosecond notation. If the timestamp exceeds 60 minutes, the timestamp is shown in an hour, minute, and second notation. The abbreviations used for the various time scales are listed in the following table. The smallest recordable timestamp is 50 ns.

Timestamp Abbreviations in the Capture Display Window

Time Unit	Abbreviation
Nanoseconds	ns
Microseconds	μ s
Milliseconds	ms
Seconds	s
Minutes	mi
Hours	hr

Read the Mnemonics Column

Various mnemonics appear in the right column of the capture display to provide a quick interpretation of the captured GPIB events. The column may also show line transitions. If the line name is followed by an up arrow (↑), the line transitioned from unasserted to asserted. If the line name is followed by a down arrow (↓), the line transitioned from asserted to unasserted. Note that if the analyzer is capturing handshake line transitions, the assertion of DAV represents a GPIB data byte or command byte. For a detailed list of the mnemonics and their meanings, refer to [Capture Display Mnemonics](#).

Print and Save

To print the contents of an inactive Capture Display window, use **File»Print...** You can print the entire capture display or limit the printing to captured events between particular markers.

Both inactive and active (if capturing is turned off) capture displays can be saved to a file. To save the data in a Capture Display window, use **File»Save As...** Whenever possible, use the .CAP extension for saving capture display files. Captured data is saved in an analyzer-specific format and can be reopened as an inactive capture display.

You can also export an inactive capture display as an ASCII text file to another application, such as a word processor. Use **File»Export...** to export the captured data. You can export captured data as text in both detailed and summarized formats. You cannot import the ASCII text file back into the GPIB analyzer.

Search for a Capture Event

To search for a specific GPIB event within a capture display from the current cursor location, complete the following steps:

1. Switch to an inactive Capture Display window.
2. Click the **Find...** button.
3. Enter your search criteria in the **Find** dialog box.

To find a trigger point in the Capture Display window, check the **Find Trigger** checkbox.

To find a particular data and control line pattern, set the pattern of the data lines using either the **ASCII** or **Hex** edit controls or the **D8** to **D1** spin controls (for binary values), and set the pattern of the control lines using the **EOI**, **ATN**, **SRQ**, **REN**, **IFC**, **NRFD**, **NDAC**, and **DAV** spin controls. Notice that the spin controls allow you to select **0** (unasserted), **1** (asserted), or **x** (don't care) for each data and control line.

To find a series of GPIB data and control line patterns, use the **Insert Above**, **Insert Below**, and **Delete** buttons to add and remove entries from the **Find String** list box until it contains the desired series of GPIB data and control line patterns.

Use the **Search Direction** switch to specify the direction to search from the current cursor position in the capture display.

4. Click the **Find** button in the **Find** dialog box. This action automatically closes the **Find** dialog box and takes you from the current cursor position to the first GPIB event in the capture display that matches your search criteria.

To find the next occurrence, click the **Find Next** button.

Mark Capture Events to Show Statistics

Markers are allowed only in inactive capture displays. All inactive capture displays contain at least two markers: **Begin** and **End**. Single-clicking places the cursor in a capture display. Double-clicking places markers in a capture display and removes placed markers. Markers are labeled **M0**, **M1**, **M2**, and so on, as they are created.

After you have placed your markers, you can use the **From** and **To** controls in the **Markers & Statistics** group box to examine statistics about the captured data.

If you are using summarized display mode, you might have more than one marker for each line. In this case, the letter *M* appears in the marker column. You can click the *M* several times to see each marker for that line.

Common Questions

Why can't I use the analyzer to monitor a GPIB application which uses the NI-488.2 `ibln` or `FindLstn` command?

You can use the analyzer to monitor an application with these commands, but you cannot select **Participate in Acceptor Handshaking** in the **Settings** dialog box of the analyzer. Selecting this feature asserts/unasserts the NDAC and NRFD lines in response to the Talker's assertion/unassertion of DAV in the GPIB handshake sequence. Therefore, when you run an application that executes a `FindLstn` or `ibln` command, all possible GPIB addresses are returned.

How does selecting "Participate in Acceptor Handshake" in the Settings dialog box affect the GPIB?

When **Participate in Acceptor Handshake** is selected, the analyzer circuitry behaves like a GPIB Listener for the duration of the capture and participates in acceptor handshaking on the GPIB. You can use this feature to slow down GPIB transfers to a particular rate and to avoid overflow errors.

How do I choose a handshake rate? What does "Maximum" mean?

You can use the handshake rate to slow down the transfer rate on the GPIB while debugging timing-related problems. Choosing a particular handshake rate guarantees that the transfer rate on the bus will be less than or equal to that rate. Choosing the **Maximum** rate causes the analyzer to respond as a Listener as fast as it can without causing overflow errors.

How do I define a trigger point to capture a command byte such as TA0?

In the **Settings** dialog box, set the data lines of the trigger condition by entering either the ASCII or hex equivalent of TA0 or set each of the data lines independently to represent TA0. Set the ATN, DAV, and NDAC lines to 1. Set NRFD to 0. The remainder of the control lines should be set to x. This state of the handshake lines is necessary to guarantee that valid data is present on the data lines.

What do the rows of lights and switches in the Bus Monitor window represent?

The LEDs represent the state of the bus lines at all times. The toggle switches represent the assertion of lines from within the Bus Monitor window of the analyzer. So, if the LED for a particular line is on, and the switch for that line is

off (down position), the line is asserted, but not by the Bus Monitor.

What is the difference between active and inactive capture displays?

Active capture displays show GPIB events as they are being captured. In other words, active capture displays are windows into the single capture buffer used to store new GPIB events. Inactive capture displays show previously captured GPIB events statically, so that they are unaffected by newly captured GPIB events. You must make the capture display inactive if you want to use the search or print features.

What do the "Capture Settings" in the Capture Display window mean?

The **Capture Settings** section of the Capture Display window shows the capture settings that were used when the data in the window was captured. They help you interpret the captured data in the Capture Display window. They are not necessarily the same as the current capture settings.

How do I use the timestamping information in detailed display mode and summarized display mode?

In detailed display mode, where each line can correspond to only one capture event, the timestamp value represents the time elapsed between the event on that line and the previous event. So, if you want to determine the time elapsed between the capture of the first event and the fifth event, add up the timestamp values on the second, third, fourth, and fifth lines.

In summarized display mode, where more than one event can be present on a line, the timestamp value represents the time elapsed between the first event on that line and the first event on the previous line.

How can I prevent overflow errors?

For detailed information about avoiding overflow errors, refer to the [Avoid Overflow Errors](#) section.

GPIB Basics

The ANSI/IEEE Standard 488.1-1987, also known as GPIB (General Purpose Interface Bus), describes a standard interface for communication between instruments and controllers from various vendors. It contains information about electrical, mechanical, and functional specifications. The GPIB is a digital, 8-bit parallel communications interface with data transfer rates of 1 Mbytes/s and above. The bus supports one System Controller, usually a computer, and up to 14 additional instruments. The ANSI/IEEE Standard 488.2-1987 extends IEEE 488.1 by defining a bus communication protocol, a common set of data codes and formats, and a generic set of common device commands.

[Talkers, Listeners, and Controllers](#)

[Controller-in-Charge and System Controller](#)

[GPIB Addressing](#)

[Data and Command Messages](#)

[Handshaking](#)

[Managing and Controlling the GPIB](#)

[Setting Up and Configuring Your System](#)

[Serial Polling](#)

[Parallel Polling](#)

[HS488 Transfers](#)

[Terminating Data Transmissions](#)

[GPIB Commands](#)

Talkers, Listeners, and Controllers

GPIB devices can be Talkers, Listeners, or Controllers. A Talker sends out data messages. Listeners receive data messages. The Controller, usually a computer, manages the flow of information on the bus. It defines the communication links and sends GPIB commands to devices.

Some devices are capable of playing more than one role. A digital voltmeter, for example, can be a Talker and a Listener. If your personal computer has a National Instruments GPIB interface board and the NI-488.2 software installed, it can function as a Talker, Listener, and Controller.

Controller-In-Charge and System Controller

You can have multiple Controllers on the GPIB, but only one Controller at a time can be the active Controller, or Controller-In-Charge (CIC). The CIC can either be an active or inactive (Standby) Controller. Control can pass from the current CIC to an idle Controller, but only the System Controller, usually a GPIB interface board, can make itself the CIC.

GPIB Addressing

All devices and boards connected to the GPIB must be assigned a unique GPIB address. The Controller uses the addresses to identify each device when sending or receiving data. A GPIB address is made up of two parts: a primary address and an optional secondary address. You usually set the address using switches on the board or device.

The primary address is a number in the range 0 to 30. The GPIB Controller uses the primary address to form a talk or listen address that is sent over the GPIB when communicating with a device.

A talk address is formed by setting bit 6, the TA (Talk Active) bit of the GPIB address. A listen address is formed by setting bit 5, the LA (Listen Active) bit of the GPIB address. For example, if a device is at address 1, the Controller sends hex 41 (address 1 with bit 6 set) to make the device a Talker. Because the Controller is usually at primary address 0, it sends hex 20 (address 0 with bit 5 set) to make itself a Listener. The following table shows the configuration of the GPIB address bits.

Bit Position	7	6	5	4	3	2	1	0
Meaning	0	TA	LA	GPIB Primary Address (range 0 to 30)				

With some devices, you can use secondary addressing. A secondary address is a number in the range hex 60 to hex 7E. When secondary addressing is in use, the Controller sends the primary talk or listen address of the device, followed by the secondary address of the device.

Data and Command Messages

Eight data lines, DIO1 through DIO8, carry both data messages and command messages. All commands and most data use the 7-bit ASCII or ISO code set, in which case the eighth bit, DIO8, is either not used or used for parity. Command messages are sent with the ATN line asserted; data messages are sent with the ATN line unasserted.

Handshaking

Three hardware handshake lines asynchronously control the transfer of message bytes between devices. This process is a three-wire interlocked handshake, and it guarantees that devices send and receive message bytes on the data lines without transmission errors.

Line	Description
NRFD (not ready for data)	Listening device is ready/not ready to receive a data byte. This line is driven by all devices when receiving commands, but only by Listeners when receiving data messages. It is also used by the Talker to signal high-speed transfers (HS488).
NDAC (not data accepted)	Listening device has/has not accepted a message byte. This line is driven by all devices when receiving commands, but only by Listeners when receiving data messages.
DAV (data valid)	Talking device indicates signals on data lines are stable (valid) data and can be accepted safely by devices. The Controller controls DAV when sending commands and the Talker controls DAV when sending data messages.

The handshaking sequence is as follows:

1. The Talker unasserts DAV and then monitors the NDAC and NRFD lines that are controlled by the Listener.
2. The Talker places a byte of data on the DIO lines.
3. The Talker waits for NRFD to be unasserted by the Listener.
4. The Talker asserts DAV.
5. The Listener(s) immediately assert(s) NRFD, which acknowledges to the Talker that the current byte is being processed.
6. Listener accepts the current byte and unasserts NDAC.
7. The Talker unasserts DAV.
8. The Listener(s) assert(s) NDAC in preparation for the next byte.


Managing and Controlling the GPIB

Five GPIB hardware lines manage the flow of information across the bus. These lines are referred to as interface management lines or control lines.

Line	Description
ATN (attention)	The Controller-In-Charge (CIC) drives this line to indicate the type of message present on the data lines. ATN is asserted when the message is a command from the CIC; it is unasserted when the message is a data byte from a Talker.
IFC (interface clear)	The System Controller drives the IFC line to initialize the bus and make itself CIC. When IFC is asserted, all devices return to a known, quiescent state.
REN (remote enable)	The System Controller drives the REN line to place devices in remote or local program mode.
SRQ (service request)	Any device can assert the SRQ line to asynchronously request service from the Controller-In-Charge. SRQ remains asserted until the device is serial polled. The CIC should monitor the SRQ line, poll the device, and determine the type of service that the device needs.
EOI (end or identify)	If a device uses the EOI line to mark the end of a data message, it asserts EOI along with the last byte of data. A Listener stops reading data when EOI is asserted. The Controller also asserts the EOI line when it conducts a parallel poll.


Setting Up and Configuring Your System

Devices are usually connected with a cable assembly consisting of a shielded 24-conductor cable with both a plug and receptacle connector at each end. With this design, you can link devices in a linear configuration, a star configuration, or a combination of the two. The following picture shows the linear and star configurations.



Controlling More Than One Board

Multiboard drivers, such as the NI-488.2 driver for Windows, can control more than one interface board. The following picture shows an example of a multiboard system configuration. gpib0 is the access board for the voltmeter, and gpib1 is the access board for the plotter and printer. The control functions of the devices automatically access their respective boards.



Configuration Requirements

To achieve the high data transfer rate that the GPIB was designed for, you must limit the physical distance between devices and the number of devices on the bus. The following restrictions are typical:

- A maximum separation of 4 m between any two devices and an average separation of 2 m over the entire bus.
- A maximum total cable length of 20 m.
- A maximum of 15 devices connected to each bus, with at least two-thirds powered on.

For high-speed operation, the following restrictions apply:

- All devices in the system must be powered on.
- Cable lengths should be as short as possible up to a maximum of 15 m of cable in each system.
- At least one equivalent device load per meter of cable.

If you want to exceed these limitations, you can use bus extenders to increase the cable length or expanders to increase the number of device loads. Extenders and expanders are available from National Instruments.

Serial Polling

You can use serial polling to obtain specific information from GPIB devices when they request service. When the GPIB SRQ line is asserted, it signals the Controller that a service request is pending. The Controller must then determine which device asserted the SRQ line and respond accordingly.


IEEE 488 devices request service from the GPIB Controller by asserting the GPIB SRQ line. When the Controller acknowledges the SRQ, it serial polls each open device on the bus to determine which device requested service. Any device requesting service returns a status byte with bit 6 set and then unasserts the SRQ line. Devices not requesting service return a status byte with bit 6 cleared. Manufacturers of IEEE 488 devices use lower order bits to communicate the reason for the service request or to summarize the state of the device.

In addition to setting bit 6 when requesting service, IEEE 488.2 devices also use two other bits to specify their status. Bit 4, the Message Available bit (MAV), is set when the device is ready to send previously queried data. Bit 5, the Event Status bit (ESB), is set if one or more of the enabled IEEE 488.2 events occurs. These events include power-on, user request, command error, execution error, device-dependent error, query error, request control, and operation complete. The device can assert SRQ when ESB or MAV is set, or when a manufacturer-defined condition occurs.

Serial polling obtains specific information from a device. When you serial poll, the Controller sends a special command message—Serial Poll Enable (SPE)—to the device, directing it to return its serial poll status byte. The SPE message sets the IEEE 488.1 serial poll mode in the device, so when the device is addressed to talk, it returns a single 8-bit status byte. This serial poll status byte is different for each type of instrument; except for one bit, you must refer to the instrument user manual for information on the other bits. Bit 6 (hex 40) of any serial poll status byte indicates whether a device requested service by asserting the SRQ line. The device uses the other seven bits of the status byte to specify why it needs attention.

After the Controller reads the status byte, it sends another command message, Serial Poll Disable (SPD), to the device. The SPD message terminates the serial poll mode, thus returning the device to its normal Talker/Listener state. Once a device requesting service is serial polled, it usually unasserts the SRQ line.

When a serial poll is conducted, the following sequence of events occurs:



Parallel Polling

Although parallel polling is not widely used, it is a useful method for obtaining the status of more than one device at the same time. The advantage of a parallel poll is that it can easily check up to eight individual devices at once. In comparison, eight separate serial polls would be required to check eight devices for their serial poll response bytes.

You can implement parallel polling with either NI-488 functions or NI-488.2 routines. If you use NI-488.2 routines to execute parallel polls, you do not need extensive knowledge of the parallel polling messages. However, you should use the NI-488 functions for parallel polling when the GPIB board is not the Controller and must configure itself for a parallel poll and set its own individual status bit (ist).

A parallel poll is an exchange of messages between the Controller and other system devices. The Controller sends the IDY message true to the other devices; each device responds to the IDY message by sending one PPR message (PPR1, PPR2, PPR3, PPR4, PPR5, PPR6, PPR7, or PPR8) to the Controller. Each device usually sends a different PPR message. Each device can send its PPR message either true or false. Each device examines its local ist message and its Sense bit (S) to determine whether it will send its PPR message true or false. The following table illustrates how the ist message and the Sense bit affect the value of the PPR message.

ist message	Sense Bit (S)	PPR Message Sent
0 (False)	0	True
0 (False)	1	False
1 (True)	0	False
1 (True)	1	True

The ist message usually reflects a bit of status information about the device. For example, when the device has taken a measurement, it can assert its local ist message. The Sense bit is part of the configuration of a device. Each device has an independent Sense bit.

The meaning of the PPR message and the local ist message is device dependent.

Configuring a Device for Parallel Polls

To configure a device to respond to parallel polls, you must supply the device with two pieces of data:

- The PPR message that the device should send to the Controller (PPR1, PPR2, . . . , or PPR8).
- The value of the Sense bit of the device.

You can configure devices locally or remotely. You locally configure (Parallel Poll function subset PP2) a device by setting knobs or switches on the front panel of the device (or by physically manipulating the device in some other way). You remotely configure (Parallel Poll function subset PP1) a device by sending messages across the GPIB from the Controller to the device.

Determining the PPE Message

The Parallel Poll Enable (PPE) message contains the parallel poll configuration data for a device. When configuring remotely, the PPE message is always preceded by the Parallel Poll Configure (PPC) message. The following table shows how you determine the value of DIO[7:1] for the PPE message. As with all commands, the DIO[8] is a "don't care" bit.


Sense Bit (S)	PPR Message to Send	PPE Message (hex)
0	PPR1	60
0	PPR2	61
0	PPR3	62
0	PPR4	63
0	PPR5	64
0	PPR6	65
0	PPR7	66
0	PPR8	67
1	PPR1	68
1	PPR2	69
1	PPR3	6A
1	PPR4	6B
1	PPR5	6C
1	PPR6	6D
1	PPR7	6E
1	PPR8	6F

HS488 Transfers


National Instruments has designed a high-speed data transfer protocol for IEEE 488 called HS488. This protocol increases performance for GPIB reads and writes up to 8 Mbytes/s, depending on your system.

HS488 is a superset of the IEEE 488 standard; thus, you can mix IEEE 488.1, IEEE 488.2, and HS488 devices in the same system. If HS488 is enabled, the TNT4882C hardware implements high-speed transfers automatically when communicating with HS488 instruments.

The following picture shows a typical IEEE 488.1 data transfer. The HS488 protocol modifies the IEEE 488.1 Source Handshake and Acceptor Handshake functions. At the beginning of each data transfer, the HS488 source and acceptor functions determine whether all active Talkers and Listeners are capable of HS488 transfers. If the addressed devices are HS488 capable, they use the HS488 noninterlocked handshake protocol for that data transfer. If any addressed device is not HS488 capable, the transfer continues using the standard three-wire handshake.



The following steps describe a typical sequence of events in an HS488 data transfer in which the Talker and Listener are both HS488 capable.



1. The Controller addresses devices and becomes Standby Controller by unasserting ATN.
2. The Listener asserts NDAC and NRFD.
3. The Listener unasserts NRFD as it becomes ready to accept a byte.
4. After allowing time for the Listener to detect NRFD unasserted, the Talker indicates that it is capable of HS488 operation by sending the HSC message. To send the HSC message true, the Talker asserts the NRFD signal.
5. After allowing time for the Listener to respond to the HSC message, the Talker sends the HSC message false. To send the HSC message false, the Talker unasserts the NRFD signal.
6. When the Talker has a byte ready to send, it drives the data on the DIO signal lines, allows some settling time, and asserts DAV.
7. The Listener unasserts NDAC. HS488 Listeners do not assert NRFD as IEEE 488.1 devices would. Because of this behavior, the Talker determines that the addressed Listener is capable of HS488 transfers.
8. The Talker unasserts DAV and begins to drive the next data byte on the GPIB.
9. After allowing some settling time, the Talker asserts DAV.
10. The Listener latches the byte in response to the assertion (falling) edge of DAV.
11. After allowing some hold time, the Talker unasserts DAV and drives the

next data byte on the DIO signal lines.

12. Steps 9-11 are repeated for each data byte.

System Configuration

The HS488 Acceptor Handshake and Source Handshake interface functions depend on several time delays. Some of these delays are a function of the total system cable length.

The Controller must communicate this system configuration data to HS488 devices after the system powers on. The Controller configures HS488 devices by sourcing two multiline messages while ATN is true. The first message is the CFE message. The Controller sends the CFE message by driving a bit pattern (1E hex) that the IEEE 488.1 standard does not define on the DIO signal lines. The CFE message enables HS488 devices to interpret the SCG message that follows. The second message is a Secondary Command Group (SCG) message that contains the configuration data. The Secondary command has the bit pattern $6n$ hex, where n is the meters of cable in the system.

Terminating Data Transmissions

GPIB data transfers are terminated either when the GPIB EOI line is asserted with the last byte of a transfer or when a preconfigured end-of-string (EOS) character is transmitted. By default, the NI-488.2 driver asserts EOI with the last byte of writes, and the EOS modes are disabled.

If EOT mode is enabled, the NI-488.2 driver asserts the GPIB EOI line when the last byte of a write is sent out on the GPIB. If it is disabled, the EOI line is not asserted with the last byte of a write.

EOS mode configuration includes the following information:

- A 7-bit or 8-bit EOS byte.
- EOS comparison method. This method indicates whether the EOS byte has seven or eight significant bits. For a 7-bit EOS byte, the eighth bit of the EOS byte is ignored.
- EOS write method. If this method is enabled, the NI-488.2 driver automatically asserts the GPIB EOI line when the EOS byte is written to the GPIB. If the buffer passed into an `ibwrt` call contains five occurrences of the EOS byte, the EOI line is asserted as each of the five EOS bytes are written to the GPIB. If an `ibwrt` buffer does not contain an occurrence of the EOS byte, the EOI line is not asserted (unless the EOT mode is enabled, in which case the EOI line is asserted with the last byte of the write).
- EOS read method. If this method is enabled, the NI-488.2 driver terminates `ibrd`, `ibrda`, and `ibrdf` calls when the EOS byte is detected on the GPIB, when the GPIB EOI line is asserted, or when the specified count is reached. If the EOS read method is disabled, `ibrd`, `ibrda`, and `ibrdf` calls terminate only when the GPIB EOI line is asserted or the specified count has been read.

You can use the `ibconfig` function to configure the software to inform you whether the GPIB EOI line was asserted when the EOS byte was read. Use the `IbcEndBitIsNormal` option to configure the software to report only the END bit in `ibsta` when the GPIB EOI line is asserted. By default, the NI-488.2 driver reports END in `ibsta` when either the EOS byte is read in or the EOI line is asserted during a read.

GPIB Commands

GPIB commands are used to manage the GPIB interface system. They include commands such as untalk (UNT), which commands all GPIB devices to stop sourcing data bytes. The IEEE 488 standard also refers to GPIB command bytes as multiline interface messages. The IEEE 488 multiline interface messages are shown in the following table.

In the following table, the first group of columns (hex 00-1F) represents the primary GPIB commands. The next group of columns (hex 20-3F) corresponds to listen addresses (MLA). The listen address of a device is formed by adding hex 20 to the GPIB primary address. The next group of columns (hex 40-5F) correspond to talk addresses (MTA). The talk address of a device is formed by adding hex 40 to the GPIB primary address. (You may need to stretch this window to see the table correctly.)

Multiline Interface Command Messages

Hex	Oct	Dec	ASCII	Msg	Hex	Oct	Dec	ASCII	Msg
00	000	0	NUL		20	040	32	SP	MLA0
01	001	1	SOH	GTL	21	041	33	!	MLA1
02	002	2	STX		22	042	34	"	MLA2
03	003	3	ETX		23	043	35	#	MLA3
04	004	4	EOT	SDC	24	044	36	\$	MLA4
05	005	5	ENQ	PPC	25	045	37	%	MLA5
06	006	6	ACK		26	046	38	&	MLA6
07	007	7	BEL		27	047	39	'	MLA7
08	010	8	BS	GET	28	050	40	(MLA8
09	011	9	HT	TCT	29	051	41)	MLA9
0A	012	10	LF		2A	052	42	*	MLA10
0B	013	11	VT		2B	053	43	+	MLA11
0C	014	12	FF		2C	054	44	,	MLA12
0D	015	13	CR		2D	055	45	-	MLA13
0E	016	14	SO		2E	056	46	.	MLA14
0F	017	15	SI		2F	057	47	/	MLA15
10	020	16	DLE		30	060	48	0	MLA16
11	021	17	DC1	LLO	31	061	49	1	MLA17
12	022	18	DC2		32	062	50	2	MLA18

13	023	19	DC3		33	063	51	3	MLA19
14	024	20	DC4	DCL	34	064	52	4	MLA20
15	025	21	NAK	PPU	35	065	53	5	MLA21
16	026	22	SYN		36	066	54	6	MLA22
17	027	23	ETB		37	067	55	7	MLA23
18	030	24	CAN	SPE	38	070	56	8	MLA24
19	031	25	EM	SPD	39	071	57	9	MLA25
1A	032	26	SUB		3A	072	58	:	MLA26
1B	033	27	ESC		3B	073	59	;	MLA27
1C	034	28	FS		3C	074	60	<	MLA28
1D	035	29	GS		3D	075	61	=	MLA29
1E	036	30	RS		3E	076	62	>	MLA30
1F	037	31	US	CFE	3F	077	63	?	UNL
40	100	64	@	MTA0	60	140	96	`	MSA0,PPE
41	101	65	A	MTA1	61	141	97	a	MSA1,PPE,CFG1
42	102	66	B	MTA2	62	142	98	b	MSA2,PPE,CFG2
43	103	67	C	MTA3	63	143	99	c	MSA3,PPE,CFG3
44	104	68	D	MTA4	64	144	100	d	MSA4,PPE,CFG4
45	105	69	E	MTA5	65	145	101	e	MSA5,PPE,CFG5
46	106	70	F	MTA6	66	146	102	f	MSA6,PPE,CFG6
47	107	71	G	MTA7	67	147	103	g	MSA7,PPE,CFG7
48	110	72	H	MTA8	68	150	104	h	MSA8,PPE,CFG8
49	111	73	I	MTA9	69	151	105	i	MSA9,PPE,CFG9
4A	112	74	J	MTA10	6A	152	106	j	MSA10,PPE,CFG10
4B	113	75	K	MTA11	6B	153	107	k	MSA11,PPE,CFG11
4C	114	76	L	MTA12	6C	154	108	l	MSA12,PPE,CFG12
4D	115	77	M	MTA13	6D	155	109	m	MSA13,PPE,CFG13
4E	116	78	N	MTA14	6E	156	110	n	MSA14,PPE,CFG14
4F	117	79	O	MTA15	6F	157	111	o	MSA15,PPE,CFG15
50	120	80	P	MTA16	70	160	112	p	MSA16,PPD
51	121	81	Q	MTA17	71	161	113	q	MSA17,PPD
52	122	82	R	MTA18	72	162	114	r	MSA18,PPD
53	123	83	S	MTA19	73	163	115	s	MSA19,PPD

54	124	84	T	MTA20	74	164	116	t	MSA20,PPD
55	125	85	U	MTA21	75	165	117	u	MSA21,PPD
56	126	86	V	MTA22	76	166	118	v	MSA22,PPD
57	127	87	W	MTA23	77	167	119	w	MSA23,PPD
58	130	88	X	MTA24	78	170	120	x	MSA24,PPD
59	131	89	Y	MTA25	79	171	121	y	MSA25,PPD
5A	132	90	Z	MTA26	7A	172	122	z	MSA26,PPD
5B	133	91	[MTA27	7B	173	123	{	MSA27,PPD
5C	134	92	\	MTA28	7C	174	124		MSA28,PPD
5D	135	93]	MTA29	7D	175	125	}	MSA29,PPD
5E	136	94	^	MTA30	7E	176	126	~	MSA30,PPD
5F	137	95	_	UNT	7F	177	127	DEL	

Message Definitions

CFE	Configuration Enable
CFG	Configure
DCL	Device Clear
GET	Group Execute Trigger
GTL	Go To Local
LLO	Local Lockout
MLA	My Listen Address
MSA	My Secondary Address
MTA	My Talk Address
PPC	Parallel Poll Configure
PPD	Parallel Poll Disable
PPE	Parallel Poll Enable
PPU	Parallel Poll Unconfigure
SDC	Selected Device Clear
SPD	Serial Poll Disable
SPE	Serial Poll Enable
TCT	Take Control
UNL	Unlisten
UNT	Untalk

Important Information

[Warranty](#)

[Copyright](#)

[Trademarks](#)

[Patents](#)

[Warning Regarding Use of NI Products](#)

Warranty

The GPIB hardware is warranted against defects in materials and workmanship for a period of two years from the date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace equipment that proves to be defective during the warranty period. This warranty includes parts and labor.

The media on which you receive National Instruments software are warranted not to fail to execute programming instructions, due to defects in materials and workmanship, for a period of 90 days from date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace software media that do not execute programming instructions if National Instruments receives notice of such defects during the warranty period. National Instruments does not warrant that the operation of the software shall be uninterrupted or error free.

A Return Material Authorization (RMA) number must be obtained from the factory and clearly marked on the outside of the package before any equipment will be accepted for warranty work. National Instruments will pay the shipping costs of returning to the owner parts which are covered by warranty.

National Instruments believes that the information in this document is accurate. The document has been carefully reviewed for technical accuracy. In the event that technical or typographical errors exist, National Instruments reserves the right to make changes to subsequent editions of this document without prior notice to holders of this edition. The reader should consult National Instruments if errors are suspected. In no event shall National Instruments be liable for any damages arising out of or related to this document or the information contained in it.

Except as specified herein, National Instruments makes no warranties, express or implied, and specifically disclaims any warranty of merchantability or fitness for a particular purpose. Customer's right to recover damages caused by fault or negligence on the part of National Instruments shall be limited to the amount theretofore paid by the customer. National Instruments will not be liable for damages resulting from loss of data, profits, use of products, or incidental or consequential damages, even if advised of the possibility thereof. This limitation of the liability of National Instruments will apply regardless of the form of action,

whether in contract or tort, including negligence. Any action against National Instruments must be brought within one year after the cause of action accrues. National Instruments shall not be liable for any delay in performance due to causes beyond its reasonable control. The warranty provided herein does not cover damages, defects, malfunctions, or service failures caused by owner's failure to follow the National Instruments installation, operation, or maintenance instructions; owner's modification of the product; owner's abuse, misuse, or negligent acts; and power failure or surges, fire, flood, accident, actions of third parties, or other events outside reasonable control.

Copyright

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, storing in an information retrieval system, or translating, in whole or in part, without the prior written consent of National Instruments Corporation.

Trademarks

CVI™, National Instruments™, NI-488.2™, and ni.com™ are trademarks of National Instruments Corporation.

Product and company names mentioned herein are trademarks or trade names of their respective companies.

Patents

For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the patents.txt file on your CD, or ni.com/patents.

WARNING REGARDING USE OF NATIONAL INSTRUMENTS PRODUCTS

(1) National Instruments products are not designed with components and testing for a level of reliability suitable for use in or in connection with surgical implants or as critical components in any life support systems whose failure to perform can reasonably be expected to cause significant injury to a human.

(2) In any application, including the above, reliability of operation of the software products can be impaired by adverse factors, including but not limited to fluctuations in electrical power supply, computer hardware malfunctions, computer operating system software fitness, fitness of compilers and development software used to develop an application, installation errors, software and hardware compatibility problems, malfunctions or failures of electronic monitoring or control devices, transient failures of electronic systems (hardware and/or software), unanticipated uses or misuses, or errors on the part of the user or applications designer (adverse factors such as these are hereafter collectively termed "system failures"). Any application where a system failure would create a risk of harm to property or persons (including the risk of bodily injury and death) should not be reliant solely upon one form of electronic system due to the risk of system failure. To avoid damage, injury, or death, the user or application designer must take reasonably prudent steps to protect against system failures, including but not limited to back-up or shut down mechanisms. Because each end-user system is customized and differs from National Instruments' testing platforms and because a user or application designer may use National Instruments products in combination with other products in a manner not evaluated or contemplated by National Instruments, the user or application designer is ultimately responsible for verifying and validating the suitability of National Instruments products whenever National Instruments products are incorporated in a system or application, including, without limitation, the appropriate design, process and safety level of such system or application.

Technical Support and Professional Services

Visit the following sections of the National Instruments Web site at ni.com for technical support and professional services:

- **Support**—Online technical support resources include the following:
 - **Self-Help Resources**—For immediate answers and solutions, visit our extensive library of [technical support resources](#) available in English, Japanese, and Spanish at ni.com/support. These resources are available for most products at no cost to registered users and include software drivers and updates, a KnowledgeBase, product manuals, step-by-step troubleshooting wizards, hardware schematics and conformity documentation, example code, tutorials and application notes, instrument drivers, discussion forums, a measurement glossary, and so on.
 - **Assisted Support Options**—[Contact NI engineers](#) and other measurement and automation professionals by visiting ni.com/ask. Our online system helps you define your question and connects you to the experts by phone, discussion forum, or email.
- **Training**—Visit ni.com/custed for [self-paced tutorials, videos, and interactive CDs](#). You also can register for instructor-led, hands-on courses at locations around the world.
- **System Integration**—If you have time constraints, limited in-house technical resources, or other project challenges, [NI Alliance Program](#) members can help. To learn more, call your local NI office or visit ni.com/alliance.
- **Declaration of Conformity (DoC)**—A DoC is our claim of compliance with the Council of the European Communities using the manufacturers declaration of conformity. This system affords the user protection for electronic compatibility (EMC) and product safety. You can obtain the [DoC](#) for your product by visiting ni.com/hardref.nsf.
- **Calibration Certificate**—If your product supports calibration, you can obtain the [calibration certificate](#) for your product at ni.com/calibration.

If you searched ni.com and could not find the answers you need, contact your [local office](#) or NI corporate headquarters. You can also visit the [Worldwide Offices](#) section of ni.com/niglobal to access the branch office Web sites, which

provide up-to-date contact information, support phone numbers, email addresses, and current events.

Clicking the **Capture** button in the Action window causes the analyzer to begin capturing GPIB events into the active capture display. Data is captured according to the current capture configuration settings. Triggering is not enabled.

Clicking the **Capture & Trigger** button in the Action window causes the analyzer to begin capturing GPIB events into the active capture display and to monitor for trigger conditions. Data is captured according to the current capture configuration settings, and triggers are monitored according to the current trigger configuration. The capture and trigger configuration can be modified using the settings configuration described in the [Settings Configuration](#) section.

Capture Display Mnemonics

The mnemonics that appear in the capture display of the GPIB analyzer are defined below.

DAB GPIB data byte captured using the data transfer or handshake line transition.

GPIB command bytes captured using the command transfer or handshake line transition:

ACG	Addressed command group.
CFE	Configuration enable.
DCL	Device clear.
GET	Group execute trigger.
GTL	Go to local.
LA0-LA30	Listen addresses 0-30.
LLO	Local lock out.
PPC	Parallel poll configure.
PPU	Parallel poll unconfigure.
SC0-SC30	Secondary command 0-30.
SDC	Selected device clear.
SPD	Serial poll disable.
SPE	Serial poll enable.
TCT	Take control.
TA0-TA30	Talk addresses 0-30.
UCG	Universal command group.
UNL	Unlisten.
UNT	Untalk.

GPIB parallel poll responses captured using the parallel poll response capture stimulus:

PP-B	Parallel poll is beginning.
PP-E	Parallel poll is ending.
PP-R	Parallel poll response (occurs between PP-B and PP-E).

This multiline interface message is a proposed extension to the IEEE 488.1 specification to support the HS488 high-speed protocol.

Branch Offices

Office	Telephone Number
Australia	61 2 9672 8846
Austria	43 0 662 45 79 90 0
Belgium	32 0 2 757 00 20
Brazil	55 11 3262 3599
Canada (Calgary)	403 274 9391
Canada (Montreal)	514 288 5722
Canada (Ottawa)	613 233 5949
Canada (Québec)	514 694 8521
Canada (Toronto)	905 785 0085
Canada (Vancouver)	514 685 7530
China	86 21 6555 7838
Czech Republic	42 02 2423 5774
Denmark	45 45 76 26 00
Finland	385 0 9 725 725 11
France	33 0 1 48 14 24 24
Germany	49 0 89 741 31 30
Greece	30 2 10 42 96 427
Hong Kong	2645 3186
India	91 80 4190000
Israel	972 0 3 6393737
Italy	39 02 413091
Japan	81 3 5472 2970
Korea	82 02 3451 3400
Malaysia	603 9059 6711
Mexico	001 800 010 0793
Netherlands	31 0 348 433 466
New Zealand	64 09 914 0488
Norway	47 0 32 27 73 00
Poland	48 0 22 3390 150
Portugal	351 210 311 210
Russia	7 095 238 7139
Singapore	65 6 226 5886
Slovenia	386 3 425 4200
South Africa	27 0 11 805 8197
Spain	34 91 640 0085
Sweden	46 0 8 587 895 00

Switzerland	41 56 200 51 51
Taiwan	886 2 2528 7227
United Kingdom	44 0 1635 523545
United States (Corporate)	512 683 0100

If SC appears after a talk or listen address, it is a secondary address. If it appears after a parallel poll configure, it is either a parallel poll enable (PPE) or a parallel poll disable (PPD) command. If it appears after configuration enable (CFE), it is the cable length for HS488.